



Cascade II & III Spa Fill Instructions

1. Close outlet valve at Pump 1.
2. Fill trough until water is half way.
3. Fill main body until 2" before flow over.
4. Loosen pump 1, inlet union to release air in line & retighten.
5. Start Pump 1 then open valve.
6. If it does not start, close valve and loosen pump union and then re-tighten and try again.

Site Tube Window found on
left or right front corner of
Spa

